

Thule AirScreen XT fitment guides

Thule WingBar Evo / Thule SquareBar Evo Fit chart

Thule AirScreen XT		S 870200	M 870201	L 870202	XL 870203
Thule WingBar Evo 108 (711100/711120)	Clamp/Fixpoint		•		
	Raised Rail/Flush	•			
Thule SquareBar Evo 108 (712100)	Clamp/Fixpoint		•		
	Raised Rail/Flush	•			
Thule WingBar Evo 118 (711200/711220)	Clamp/Fixpoint			•	
	Raised Rail/Flush		•		
Thule SquareBar Evo 118 (712200)	Clamp/Fixpoint			•	
	Raised Rail/Flush		•		
Thule WingBar Evo 127 (711300/711320)	Clamp/Fixpoint			•	
	Raised Rail/Flush			•	
Thule SquareBar Evo 127 (712300)	Clamp/Fixpoint			•	
	Raised Rail/Flush			•	
Thule WingBar Evo 135 (711400/711420)	Clamp/Fixpoint				•
	Raised Rail/Flush			•	
Thule SquareBar Evo 135 (712400)	Clamp/Fixpoint				•
	Raised Rail/Flush			•	
Thule WingBar Evo 150 (711500/711520)	Clamp/Fixpoint				•
	Raised Rail/Flush				•
Thule SquareBar Evo 150 (712500)	Clamp/Fixpoint				•
	Raised Rail/Flush				•

Clamp: Thule Evo Clamp (710501)

Fixpoint: Thule Evo Fixpoint (710701)

Raised Rail: Thule Evo Raised Rail (710405) / Thule oversize rail foot (710801)

Flush: Thule Evo Flush Rail (710601)

Thule WingBar Edge Fit chart

Thule AirScreen XT		S 870200	M 870201	L 870202	XL 870203
Thule WingBar Edge 77 (721200/721220)	Clamp/Fixpoint		•		
	Raised Rail/Flush	•			
Thule WingBar Edge 86 (721300/721320)	Clamp/Fixpoint		•		
	Raised Rail/Flush	•			
Thule WingBar Edge 95 (721400/721420)	Clamp/Fixpoint			•	
	Raised Rail/Flush		•		
Thule WingBar Edge 104 (721500/721520)	Clamp/Fixpoint			•	
	(721500/721520)			•	
Thule WingBar Edge 113 (721600/721620)	Clamp/Fixpoint				•
	Raised Rail/Flush			•	

Clamp: Thule Edge Clamp (720501)

Fixpoint: Thule Edge Fixpoint (720701)

Raised Rail: Thule Edge Raised Rail (720401)

Flush: Thule Edge Flush Rail (720601)